



# How to Keurig K75 Platinum Brewing System

The vacuum mechanism within the Keurig B70 Platinum will be readjusted.

Written By: Kristen Temnyk



## INTRODUCTION

If the vacuum is malfunctioning, water will be fed into the air pump causing it to rust and seize.

---



### TOOLS:


- [Phillips #2 Screwdriver](#) (1)
  - [Phillips #00 Screwdriver](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — How to Keurig K75 Platinum Brewing System




- ⚠ Before beginning the repair, turn off and unplug the brewer from any power source.
- Move the brewer so that the bottom is easily accessible.
- Unscrew the five 4mm silver diagrammed screws using a #2 Philips Head screwdriver.

## Step 2



- Using a spudger, gently pry open the base metal plate from the brewer.
- Gently place the base of the brewer down.


## Step 3



- Locate the vacuum apparatus within the Keurig B70 Platinum.
- Using a #00 Phillips screwdriver, unscrew the three 15 mm black screws diagrammed.



## Step 4



- Using a spudger, lift the white piece of the vacuum away from the black membrane.
- Realign the circular pieces of the membrane so that the circles lie flush inside the black membrane apparatus.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 02:14:38 PM.